



Wireless Alarm for Windows and Doors AL600, AL600-3

OWNERS MANUAL

INSTALLATION

1. Select window or door to be protected.
2. Remove alarm and sensor from package. Set alarm switch to "OFF" position.
3. Before removing peel away adhesive, place alarm on window or door near an edge and place sensor on adjacent frame making sure that there is room for both to fit very closely to each other when window or door is closed.
4. Peel cover of adhesive tape from alarm and place alarm on window or door edge.
5. Peel cover of adhesive tape from sensor and place adjacent to alarm with raised arrow on sensor pointing toward top of alarm.
6. Push firmly on alarm and sensor to ensure each is solidly affixed.

OPERATION

* Pull plastic tab from alarm to activate batteries*

1. Open window or door with alarm in place.
2. Click alarm switch to "CHIME." Allow chime to sound for a few seconds, then click switch to "OFF."
3. Click alarm switch to "ALARM." Allow alarm to sound for a few seconds, then click switch to "OFF."
4. Close window or door.
5. Click switch to "CHIME" or "ALARM" based on preference.
6. Click switch to "OFF" when opening window or door. Return to "ALARM" or "CHIME" when window or door is closed.

REPLACING THE BATTERIES

1. Test alarm periodically by opening door or window with "ALARM" or "CHIME" switched on.
2. When alarm no longer sounds or is weak, change batteries.
3. Alarm requires 3 LR44 lithium button cell batteries.
4. Open battery compartment by sliding battery compartment door located at bottom of alarm in direction of raised arrow on battery compartment door.
5. Insert batteries by aligning them according to polarity and inserting them into the battery compartment. Batteries should be stacked with positive(+) side down and negative(-) side up. Polarity is noted on surface of battery face.
6. Dispose of spent batteries according to manufacturer instructions.

ACTION PRODUCTS WORLDWIDE, LLC LIMITED WARRANTY

What is covered: Any defect in materials and workmanship.
For how long: 3 years from date of purchase.

What we will do: If your product is defective and returned within 30 days after the date it was purchased, we will replace it at no charge to you. If returned after 30 days but within 3 years of the date of purchase we will repair it or, at our option, replace it at no charge to you. If we repair your product, we may use new or reconditioned replacement parts. If we choose to replace your product we may replace it with a new or reconditioned one of the same or similar design. The repair or replacement will be warranted under our standard three year warranty.

Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the product is fit for ordinary use), are limited to 3 years from the date of purchase. We will not pay for loss of time, inconvenience, loss of use of your product or property damage caused by your product or its failure to work, or any other incidental or consequential damages including personal injury. Some states do not allow limitations on how long an implied warranty lasts or the exclusion of limitation of incidental or consequential damages, so the above exclusions or limitations may not apply to you.

What we ask you to do: To get warranty service for your product you must provide proof of the date of purchase.

Within 30 days of the date it was purchased, return your product to your place of purchase for immediate replacement. After 30 days, but before the end of the 3 year warranty period, you may return the product to the following address

Customer Service Department
Action Products Worldwide, LLC
PO Box 527
Gladstone, NJ 07934

We suggest that you retain your original packaging material in the event you need to ship your product. When sending your product include your name, address, phone number, proof of date of purchase, and a description of the operating problem. After repairing or replacing your product we will ship it to your home within four weeks.

What this warranty does not cover: Among other things this warranty does not cover defects resulting from accidents, unauthorized repair, failure to follow directions, misuse, fire, floods, and acts of God. If your protection is not covered by our warranty, call our customer service number at (877) 631-3373 to determine whether we will repair your product and other repair information, including charges. We, at our option, may replace rather than repair your product with a new or reconditioned one of the same or similar design, the repair or replacement will be warranted for three years. This limited warranty is the only one we give on your product, and it sets forth all our responsibilities regarding your product. There are no warranties that extend beyond the description set forth above.

State law rights: This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.